I know the Straight Leg Lengths, Angles, and Rotations

Use "Custom Part" and change all of your "Dim Types" to "Tangent". Tangent allows for the definition of the straight lengths between bends.



