

Dimensioning - Removing a View

There are 3 views that are available in dimensioning; XY, XZ & YZ. In some cases you may desire to suppress the display of one or two of these views.

To display or suppress the display of a view, select the cell in the "Dimension Defaults" grid that represents "True" or "False" for the "Display XY View", "Display XZ View" or "Display YZ View".

