

Paste Part

This thread will show how to "Paste" a part to an assembly.

Step 1) Select a part from the "**Master Parts List**".

Step 2) Select the "**Paste Part**" command button.

Step 3) Select the "**PickPoint**" to locate the part.

