



PickPoints - Single

This is the most used method to locate PickPoints.


- Step 1) Select the **"PickPoints"** tab, then the **"Single"** tab.
- Step 2) Select the **"Select Reference Point"** command button.
- Step 3) Select the reference **"PickPoint"** from the screen.
- Step 4) Enter in the **"Values"** of distances into the correct fields.
- Step 5) Select the **"Apply"** command button.



You can continue using the same reference point as shown in the following picture.



Or you may desire to select a new reference point as shown in this picture.



NOTE: Common mistakes in this area are forgetting to select the "Apply" command button, not selecting a new reference point when desired and the **most common issue is not updating some of the fields back to 0 when needed.**