



Settings



The **Axis** allows for change in display type;
XYZ
Tri-Star



Axis Scale: Default is 4 in inches and 100 in millimeters. Increase this number for a larger Axis display

View PickPoints: Uncheck these items to suppress the display of the PickPoints

Display Picture Help: When performing most functions in assembly, a helpful hint will be displayed on your cursor. Use this field to turn this feature on an off

Best Shade: This will increase the smoothness of the model display. Using this feature will also significantly slow down and shading you do.

Background Color: This allows you to change the window color. Use this for powerful presentations.