

Calibration, what should I use; book, button?

We have changed the way we describe calibration to the customer a couple of times in the past years. The calibration as a whole hasn't changed (release 1.x of EZ is different), however, we have tried to simplify and better explain what each one of the values means in the software.

Please use this calibration document:

<http://www.2020softwaresolutions.com...ad/cgrev03.pdf>

For some of you this is the same as you will find under the "Help" menu or in the back of your book. For customers prior to 2007 it will be updated descriptions and should better help you to define your values.