


Calibrating your printer


Printers have different scaling and it is very important to calibrate your printer prior to printing out templates and using them on your tube.

Step 1) Select the "Print Scale" command button.



Step 2) Select "Ok" to print

Step 3) Retrieve the paper that was printed. It should look like the following:



Step 4) Measure the horizontal and vertical line on the paper and enter those values in decimal format into the software.

Step 5) Select the "Apply" command.

Printer Scale Results

| | |
|---|--|
|  | Horizontal Line Length: <input type="text" value="0"/> |
|  | Vertical Line Length: <input type="text" value="0"/> |

NOTE: This only needs to be done one time, unless you switch printers.