

Start using Assembly without calibrating my die?

Start using Assembly without calibrating my die?

For the most part this is Ok. When you transfer a part back to 3D or XYZ it will bring in the information for your tool. If the tooling has been updated it will automatically catch this.

The screenshot shows a software interface with two tabs: 'Part Details' and 'Cutting'. The 'Part Details' tab is active and contains a table with the following data:

Name	Type	# Bends	Length
bike01_leftb	Bends	3	80.0
bike01_right	Bends	3	80.0
Part 3	Bends	1	35.8
Part 4	Bends	1	35.8
Straight 2	Straight	0	29.2
Straight 3	Straight	0	36.5

Below the table are four buttons: 'Calc Weight' (with a scale icon), 'Transfer Part' (with an XYZ icon), 'Transfer Part' (with a 3D icon), and 'Print' (with a printer icon). At the bottom, there is a 'Part Details' section with a table showing 'Name' as 'bike01_leftbottom'.