

Custom CLR

In the case of Roll Forming you may not be able to specify a tool. Here we can specify a radius for each bend use "**Custom CLR**"

