

My Bent Part Doesn't Follow my PickPoints

My bent part doesn't follow my PickPoints.

This issue comes up on occasion, typically from new users.

The cause: (case 1) You have a bend angle of 0 degrees. This is caused by 3 points being in a line and the software can not create an arc because there is no change in direction from the center point.

The cause: (case 2) Typically this is caused from not enough distance between PickPoints to allow for the radius of your tooling.

As an example; If you are making a 2 bend "U" bracket with the 2 bends of 90 degrees than the distance between the 2 dots must be at least 2 times your CLR.