The Template Entry Boxes are Black

This is the case on some of the older versions. On some computers you may need to change your "theme" for this problem to be fixed.

To change the "theme" (this is a MicroSoft Windows function) get out of Bend-Tech and right click somewhere on your desktop without being over an icon. Select "Properties" from the list and change your theme.